


New!

Wing Nut Socket

Secure Any Wing Nut With Ease

How it works:



Attach the Wing Nut Socket (City Theatrical Part Number 1350) to a **3/8" ratchet with a push button**, to secure the socket placement.



Slide the opening over any wing nut.



Tighten or loosen the wing nut with ease, with more reliability than possible by hand.

City Theatrical P/N: **1350**
citytheatrical.com/products/wing-nut-socket

**CITY
THEATRICAL**
NEW YORK • LONDON
An Environmental Lights Company