

TOP HAT
MARTIN MAC ENCORE WASH
PN 2779

INSTALLATION GUIDE

Loosen(4) existing screws



Align accessory screw holes with existing screws.
Rotate clockwise.
Tighten (4) existing screws to fix accessory to fixture.

